


# Reversing the Direction in Which the Refrigerator Door Swings Open

For your convenience, the direction in which your refrigerator door swings open can be reversed simply by changing the position of the door hinge assemblies.



1. Gently lay the refrigerator on its back with the condenser facing the floor.
2. Remove the bottom hinge assembly on which the door is hung, by unscrewing the two hexagonal head screws on the right front corner of the bottom panel.
3. Remove the leg from the bottom and screw it into the hole on the right side.
4. Pull the door away from the top hinge assembly and set it aside.
5. Unscrew the top hinge assembly from which the door was hung and screw it into the opposite side of the refrigerator.
6. Reattach the door to the refrigerator by the top hinge assembly (now on the reverse side).
7. Reattach the bottom hinge shaft and the bottom hinge to the opposite side, screwing them in place to assure the door is properly secured.
8. The direction in which the door opens has now been reversed. The following points should be checked before returning the unit to its upright position:
  - (a) Check that the door is on straight.
  - (b) Make sure there is no space between the door gasket and the refrigerator unit itself when the door is closed.
  - (c) Check that the gasket on the hinged side is not caught between the door and the unit when the door is opened or closed. Forcing the door shut when the gasket is caught may damage the gasket.
9. After ensuring the door has been correctly reattached, it is important to tighten all the screws holding the hinges in place. If they are not tightened, the door could slip out of position or there could be a space between the door and the unit.
10. Stand the unit back in its upright position.
11. For models that open to the left, please follow the above procedure in the opposite direction.